Removal and Installation of Cart



Fold the cart into its lowest position and make sure it is laying horizontally on flat ground.







Locate the 4 bolts that attach the cart to the saw at each corner.



Remove each bolt along with the accompanied washers (2) and nut (1) from the cart and saw assembly using a 5mm allen wrench and a 13mm crescent wrench.

EXCERPT FROM THE JOBSITE SAW OWNERS MANUAL



Once the bolts are removed, lift the cart straight up and off the cart.

To re-attach the cart, reverse the steps.