



Under Table Cabinet

What's in the Box / Assembly Instructions

What's in the Box

Small Hooks - 3	Bolts - 16
Medium Hooks - 3	Flat Washers - 16
Drawer Liners - 3	Split Washers - 16
Foam Insert - 1	Locking Casters - 4

Required Tools



Setup Instructions

After unboxing your UTC, there are just a few setup steps to prepare it for use.

Installing the Casters

1. Lay the cabinet on its side or completely invert it to rest on its top so that the bottom of the cabinet is accessible. For safety, have a second person assist you with this step.
TIP: Consider resting the cabinet on the empty, collapsed shipping box for this step to protect the finish of your new cabinet.
2. Rest each of the four **Locking Casters** on the bottom of the cabinet, aligning the holes in the foot plate of the caster with the threaded holes in the cabinet.
3. Slip one **Split Washer** followed by one **Flat Washer** onto each bolt.
4. Insert the prepared bolts with washer hardware through the caster footplate and thread them into the holes on the cabinet.
5. Tighten all caster bolts using a 14mm wrench.
6. Set the cabinet upright such that it is resting on the casters. For safety, have a second person assist you with this step.

Installing the Hooks

1. Open the vertical drawer at the right side of your cabinet.
2. Install the included **Small Hooks** and **Medium Hooks** into the pattern of holes at the desired locations for convenient storage of your tools and accessories.

Customizing the Drawers

1. A **Foam Insert** is included in the vertical cabinet drawer which can be cut out for to create a custom fit for specific tools or accessories. it is recommended to lay out your tools and cut the **Foam Insert** as desired before inserting into the drawer.

Removing the Drawers

1. Pull the drawer out to its maximum extension
2. Locate the small black lever in the drawer slide shown here
3. For the right side slides, push down on the lever to release the retention latch. While holding the latch, slide the external portion of the rail slide back to release the drawer.
4. For the left side slides, push up on the lever to release the retention latch.
5. Remove the drawer

Step 2



Step 3



Step 4



Thank you for purchasing the SawStop Under Table Cabinet (UTC).
Explore other accessories from SawStop by scanning the QR code.

